

4" E-Z-Go Lift Kit (2 passenger)

Fits Years 07/2001-2003

Note: This is a bolt on lift kit. Offset wheels are recommended.



-FRONT LIFT Instructions-

Jack-up the front of the cart and place it on jack stands. Remove the wheels, tires & tie rod joints from the spindles. Remove the spindles from the front axle. Clean and lubricate these king pin bolts for the reinstallation of the spindles. Take shock loose from axle.

Remove the front axle from the leaf springs. Install new axle to spring w/ old spring plates. Install the spindles to the new front axle. Install steering riser to the passenger side spindle using provided hardware. Re-attach the tie rod joints to the spindles. Mount diamond plate cover to front spring axle.

Now you are ready for adjustments:

Mount tires. Lower cart to the ground. Push cart back & forth to get suspension to seat.

Adjust toe in 1/8" (Use straight edge on side of tires, measure from behind of tire & then adjust 1/8" in on front of tire.

NOTE: Drive cart around then check adjustments. Repeat adjustments if necessary.

4" steering riser

Shock mount

